



Programmable Strip Cutter

Model : M-70

The **SS** Programmable Strip Cutter Model M-70 is a guillotine type programmable shear that can cut card or web stock into strips of desired width. This is a very rugged machine.

M-70 is run by an inbuilt microcomputer which can be easily programmed by a 16 key keypad and LCD display provided on the front panel.



SPECIFICATIONS

Maximum Card Width	120mm
Cut Width	2-12mm
Power	220V, 50Hz
Weight	40Kg
Dimension	44cm X 35cm X 33cm (H)

FEATURES

- The cutting speed is about 5000 cuts per hour.
- The blades are easily replaceable and are made of hardened alloy steel.
- In normal operation, 1 million cuts can be made without the need for sharpening.
- The number of strip that are cut is programmable and can be varied as per requirement from 1 to 9999.
- The width of the strip is also programmable from 2mm to 12mm.
- The machine can cut laminate of width upto 10cm.
- Keyboard entry for strip width definition.
- Emergency STOP switch.
- One-year warranty against manufacturing defect.

ORDERING INFORMATION

Programmable Strip Cutter Model M-70.

ADVANCED SENSOR SYSTEMS PVT. LTD.

20, INDUSTRIAL AREA, AMBALA CANTT – 133 006, INDIA
TEL: +91-171-2699290/2699471/2699274 FAX: +91-171-2699221/2699008
Website: www.mdimembrane.com Email: mdi@vsnl.com